



FIGURE 18a. ZONES OF CONCERN FOR GROUNDWATER PLUME EXPANSION ALONG COMPILED FAULTS, BEDROCK CONTACTS, LANDSLIDES, HISTORIC AND MODERN CREEKS. SEE NEXT PAGE FOR MAP LEGEND.